
A STEP-BY-STEP GUIDE TO SETTING UP YOUR NEW LTE-A ROUTER









IN THE BOX



Make sure you have the following:


















Please refer to the label on the bottom of the router for SSID (WiFi) and the WiFi Key password details.










WPS





ROUTER DIAGRAM: Back Panel









ROUTER DIAGRAM: Underside



Setup Details

Reset Button



Sim Card Slot



STATUS LIGHTS



HUAWEI
 Y_{et} Y_e Y_e
WPS POWER
• STATUS
● WIFI ● MODE

WPS

• POWER

• LAN

LABEL	INDICATORS	EXTRA INFORMATION
$\gamma_{\rm r}/\gamma_{\rm rl}/\gamma_{\rm rll}$	No LTE-A SignalLTE-A Signal strength 1-3 Bars	
Power	No Power Power On	
Status	 No Wan Connection Wan Connected (flashing during firmware update) 	
Lan	No Lan Lan Connected (flashing during data)	
Wifi	WiFi DisabledWifi Active (flashing during WPS setup)	Press and hold the WPS button until the light starts flashing 2-5 seconds will initiate a 2.4ghz connection more than 5 seconds will initiate a 5ghz connection
Mode	No Sim / Sim Error / Connection Error Connected with Ethernet (Wan Port) Connected with 2G (GPRS) Connected with 3G Connected with LTE / LTE - A	The MWEB LTE-A service uses a pure LTE-Advanced network and will not fall back to other signal types. Other connections, such as Fibre could be made using the Wan port with this router.






INSERTING THE SIM CARD INTO THE ROUTER



Step 2



Carefully pop the micro sim card out of the plastic card.

(The smallest card inside the second set of perforations.)



SIM Card Slot

Open the SIM card slot located at the bottom of the router. Insert the sim card, cut-corner down, chip facing the sticker – into the slot. It will stick into place.





SETTING UP THE ROUTER







Plug the one end of the power cable into the back of the router and the other end into the wall socket.

Then switch on the router by pressing the power button (A) located at the back of the router.

If you plan to set up your router via WiFi continue to step 4.

If you plan to set up your router with the Ethernet cable continue to step 5.

- POWER
- STATUS
- LAN
- WIFI
- MODE

CONNECTING TO THE ROUTER VIA WiFi







Once the router is switched on (you will know the router is on when the green light on the front panel is lit up), open the list of available wireless networks on your computer by selecting the wireless signal.

Choose one of the default B618 SSIDs and click connect. The default wireless network name (SSID) and the WiFi Key password is located at the bottom of your router. Enter it to connect and skip ahead to step 6.





CONNECTING TO THE ROUTER VIA ETHERNET CABLE






Once the router is switched on (you will know the router is on when the green light on the front panel is lit up), plug the provided Ethernet Cable (A) into one of the two LAN ports (B) on the router. Plug the other end into the Ethernet port on your computer.

Ethernet Cable









CONNECTING TO THE INTERNET FOR THE FIRST TIME





Once you are connected to the router via WiFi or Ethernet cable, open a web browser on your computer and type in the following IP address 192.168.8.1 in the address bar and press ENTER.

(The IP address is located on a white sticker on the bottom of your router along with the default WiFi name and password).

The Log In screen will appear automatically.

If you don't want to change any settings, such as the WiFi network name or password, just click cancel and start browsing.

To log in and change router settings, type admin in the username field and admin in the password field.

HUAWEI		at ti 😂
Quick Setup	Configure WLAN Settings	Step 1 of 2
	Name 55ID (Service Set Identifier): Enter a character sto length, as the name for your weekes local area network (V	
		Next
	To better protect your device, please from the initial configuration. The initial configuration can help you modify the device \$1500, update the device automatically, and modify the default accreamd. User name: ammin	
niacy Palicy	Eorgol password Log In Cancel) Open Source fee




Modify Password Password strength can be low, medium, or high. For more infor Current password: New password: Password strength: Low Middle High Confirm password:

CHANGING YOUR ROUTER SETTINGS




The quick setup wizard will launch automatically

Step 7



Change the Default Wifi settings if required. This means you can choose your own WiFi network name (SSID).



Tick modify password and type in the password of your choice into the WLAN key field. Click next.




CHANGING YOUR ROUTER SETTINGS





W HUAWEI	E	nglish 🔻	Help admin Log Out
ettings			
Quick Setup	Update Configuration		Step 2 of 3
	This configuration will allow your device to be automatic efficient and better services. We recommend that you er it later from the Settings page. Auto-update in idle period (from 3 am to 5 am). Update manually	nable auto update	
rivacy Policy	← Copyright © 2006-2016 Huawei Technologies Co., Ltd.		Open Source Not

You will now see "Update Configuration" This is to support firmware updates over the network (not currently used), leave at default settings.



Click finish and wait for settings to apply. (If you're connected to the router via WiFi and changed the network name or password, you'll have to reconnect to the router using the new WiFi settings that you created.)

You are now ready to start browsing!